




- Utilisation
- Use
- Anwendung
- Utilización







- Ordre de montage des antennes
- Fitting aerials

- Montage der antennen
- Montaje de las antenas







EN 50083-1




- Préparation des câbles
- Preparing cables

- Vorbereitung der Kabel
- Preparación de los cables




- Repérage des câbles
- Marking cables
- Markierung der Kabel
- Identificación de los cables




- Réglage
- Setting
- Einstellung
- Ajuste

- Fixation / Branchement
- Fixing / Connections
- Befestigung / Anschluss
- Fijación / Conexión





- A • Si non utilisé
- If not used
- Falls unbenutzt
- Si no se utiliza




- Réglage
- Einstellung
- Setting
- Ajuste

- Partir de 0, tourner progressivement
- Starting at 0, turn gradually
- Von 0 ausgehen, progressiv drehen
- Partir de 0, girar progresivamente



- Signal TV insuffisant
- TV signal too weak
- Fernsehsignal unzureichend
- Seâl de TV insuficiente



- Signal TV excessif
- TV signal too strong
- Fernsehsignal zu stark
- Seâl de TV excsiva





60 dB  $\mu$ B < TV < 85 dB  $\mu$ V  
 50 dB  $\mu$ B < FM < 66 dB  $\mu$ V  
 47 dB  $\mu$ B < SAT < 77 dB  $\mu$ V

- Signal insuffisant < 50 dB
- Signal too weak < 50 dB



- Fernsehsignal unzureichend < 50 dB
- Seâl insuficiente < 50 dB




10 dB




13 dB



16 dB



NO



OK

